




BRIO 756 - Inlet valve refill 15/16P

SIAMP



FLAP MAESTRO - Outlet valve









SETTINGS



Adjust the stop ball position
Unclip and re-clip the stop ball

For the button, you should feel
a free stroke before actuation

MAINTENANCE



SIAMP

Manufacture : SIAMP Ltd.
 Lot E1, Street K1, Cat Lai IZ,
 Thanh My Loi Ward, District 2
 Ho Chi Minh City, Vietnam

Tel : +84 28 37 422 116
 Fax : +84 28 37 422 085
 contact@siamp.com.vn
 www.siamp.com / www.siamp.com.vn