



# FLAP MAESTRO - Single flush


# SIAMP




Adjust the hook position  
Unclip and clip back the stop ball




# MSE LFV - Double flush







## Maintenance




BT 40



## R24 - Inlet Valve



## Refill tube



**SIAMP**

Lot E1, Street K1, Cat Lai IZ, Thanh My Loi Ward  
 District 2, Ho Chi Minh City, VIETNAM  
 Tel: +84 28 37 422 116 - Fax: +84 28 37 422 085  
 contact@siamp.com.vn / www.siamp.com / www.siamp.com.vn