


UNISIPHON


INSTRUCTIONS

Water level adjustment




Adjust top mark to cistern water level

Flush volume adjustment



- 2 • turn off inlet valve,
• flush,
• Fill in cistern using a graduated cup in order to know flush water volume,
• Whenever flush water volume is not enough lower body level, if it is too much lift it.

Important width cistern



• Backnut tightening torque < 15 Nm



• Do not use any lubricant or grease