



99T Low pressure  
3/8" Brass




99T Low pressure  
1/2" Brass




99T Low pressure  
1/2" Plastic




## 1. Height setting




## 2. Inlet installation






### 3. Water level adjustment



Adjust water level with the grey adjustable screw ; screw to increase water level, unscrew to decrease it.



## 4. Maintenance

---



---

### WARNINGS:

- An approved single check valve or some other no less effective backflow prevention device shall be fitted at the point of connection(s) between the supply and the fitting.
- Do not over tight in any case.
- Do not use any sealing paste and/or compound in any case

**SIAMP UK will be not responsible in case these warnings are not respected.**

---