





99T Low pressure  
1/2" Brass


**INLET VALVE 99T**  
ASSEMBLY INSTRUCTIONS

## 1. Height setting





## 2. Inlet installation






### 3. Water level adjustment




Adjust water level with the grey adjustable screw; screw to increase water level, unscrew to decrease it.



2 cm min.

## 4. Maintenance



---

**WARNINGS:**

- 1) Do not over tight in any case.
- 2) Do not use any sealing paste and/or compound in any case

**NABIS** will be not responsible in case these warnings are not respected.

---