









# SIAMP

Monaco




CZ: Návod pro montáž a údržbu  
DAN: Brugsanvisning  
DEU: Bedienungsanleitung  
ESP: Manual de uso  
FRA: Notice de montage et de maintenance  
GB: Assembly and maintenance manual  
GRE: ΟΔΗΓΙΕΣ ΓΙΑ ΤΗ ΣΥΝΑΡΜΟΛΟΓΗΣΗ ΚΑΙ ΤΗ ΣΥΝΤΗΡΗΣΗ  
H: Kezelési és karbantartási útmutató  
LT: Naudojimo instrukcija  
NER: Gebruiksaanwijzing  
NOR: Bruksanvisning  
PL: Instrukcja montażu i konserwacji  
ROM: Mod de folosire  
RUS: ИНСТРУКЦИИ ПО УСТАНОВКЕ И ТЕХНИЧЕСКОМУ ОБСЛУЖИВАНИЮ  
SK: Návod na montáž a údržbu

## DADO







2 - Ref. 50 7154 00




18




19




19




19



19




20




3 - Ref. 50 7154 00




26



27




28




5 - Ref. 50 7154 00

29




30




CZ: Údržbu  
 DAN: Vedligeholdelse  
 DEU: Wartung  
 ESP: Mantenimiento  
 FRA: Maintenance  
 GB: Maintenance  
 GRE: Συντήρηση  
 H: Útmutató  
 LT: Priežiūra.  
 NER: Onderhoud  
 NOR: Vedlikehold  
 PL: Konserwacja  
 ROM: Întreținere  
 RUS: Техническое обслуживание  
 SK: Údržbu


MAINTENANCE




MAINTENANCE



MAINTENANCE




MAINTENANCE



MAINTENANCE

6 - Ref. 50 7154 00



GUARANTEED  
**5**  
YEARS